

## CITRIKLEEN® XPC

### CITRUS-BASED SOLVENT & DEGREASER

**CITRIKLEEN XPC** is a heavy duty natural biodegradable solvent.

**CITRIKLEEN XPC** is an emulsifiable solvent and can therefore be mixed and rinsed with water.

### FEATURES & BENEFITS

- Waterless
- Free of petroleum by-products
- Contains a natural solvent made from vegetable extract
- Emulsifiable
- **CITRIKLEEN XPC** is as effective as aromatic solvents
- Non-corrosive on metals
- Pleasant to use due to its citrus odour
- May be rinsed with water since it is emulsifiable



### DIRECTIONS FOR USE

PROCEDURE #1	PROCEDURE #2
<p><b>SURFACE TO BE CLEANED</b> Various industrial equipment, metallic or concrete surfaces (painted or non-painted). Replaces petroleum and chlorine based solvents.</p> <p><b>SOILS TO BE REMOVED</b> Lubricants, soot, graphite, plastic, ink, tar, asphalt, oil.</p> <p><b>WATER DILUTION</b> As is.</p> <p><b>USE PROCEDURE</b> Apply to surface with low-pressure sprayer, foamer, or with brush or cloth. Scrubbing is recommended. Rinse with high or low-pressure water.</p>	<p><b>SURFACE TO BE CLEANED</b> Cleaning of small parts</p> <p><b>SOILS TO BE REMOVED</b> Lubricants, soot, graphite, plastic, ink, tar, asphalt, oil.</p> <p><b>WATER DILUTION</b> As is.</p> <p><b>USE PROCEDURE</b> Soak in a recirculation tank containing a solution of <b>CITRIKLEEN XPC</b>. Allow to dwell 10 to 30 minutes. Once parts are removed from immersion tanks, rinse with hot water if available. (otherwise, use cold water)</p>

# CITRIKLEEN® XPC CITRUS-BASED SOLVENT & DEGREASER

## PHYSICAL PROPERTIES

Appearance	Clear, colorless liquid
Odour	Citrus
Specific gravity @ 20°C	0.865
Viscosity	< 10 cps
pH	Not applicable
Flash point (TCC)	52°C (126°F)
Boiling point	> 150°C
Freezing point	Not available
Auto ignition temperature	Not available
Foaming tendency	Low
Rinsing	Excellent
Water solubility	Forms stable emulsion

## INCOMPATIBILITY

Strong oxidizing agents

## WAREHOUSING PRECAUTIONS

Keep containers tightly closed in a dry, cool and well-ventilated place

## AVAILABLE SIZES

			
<b>20L</b>	<b>205L</b>		



## IMPORTANT

Before using **CITRIKLEEN XPC**, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

## FIRST AID MEASURES

### Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

### Skin contact

Wash with plenty of water. If skin irritation or rash occurs, get medical advice/attention. Take off contaminated clothing and wash it before re-use.

### Inhalation

If difficulties occur after mist/vapors/spray has been inhaled, remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or doctor/physician if you feel unwell.

### Ingestion

Rinse mouth. Do NOT induce vomiting. Immediately call a POISON CENTER or doctor/physician.

## PERSONAL PROTECTION



## WHMIS

