

WAREWASH - RINSE AIDS & SANITIZERS



RINSE-DRI is a low-foaming liquid rinse additive designed for use in automatic warewashing machines to promote rapid drying. It works with a companion detergent in all water conditions to rinse away food while reducing haze, filming and water spotting to provide a rapid clean and sparkling shine.

FEATURES AND BENEFITS

- Low foaming
- Brightly colored for visual confirmation of line flow
- Reduces the formation of water droplets
- Ensures even water evaporation for avoidance of haze, filming and smears
- Compatible with all makes and models of dishwashers and dispensers
- May be used manually in a three sink hand-wash operation with companion detergents and sanitizers

DIRECTIONS FOR USE

Use procedure

Use RINSE-DRI as part of a manual wash procedure or via automatic injection pump system directly to rinse cycle.
For optimum results, use in combination with West Penetone companion detergent and sanitizer products.

Concentration

For all applications and water conditions use at 23-34 uL/L or approximately 24-35 ppm_v.

Use temperature

Most effective in a hot water rinse cycle.

RINSE-DRI

AUTOMATIC WAREWASH LIQUID RINSE AID

PHYSICAL PROPERTIES

Appearance	Pink liquid
Odour	Alcohol/detergent
Specific Gravity @ 20°C	1.015-1.030
Viscosity	Thin
pH	6.5-8.0
Flash Point (TCC)	None
Boiling Point	Approx. 100°C
Freezing Point	Approx. 0°C
Foaming Tendency	Low
Concentration monitoring techniques	Not applicable
Water Solubility	Complete
Rinsability	Excellent

INCOMPATIBILITY

Acids and oxidizing materials

WAREHOUSING PRECAUTIONS

Keep from freezing
Keep container closed when not in use

AVAILABLE SIZES

			
4L	20L		

FIRST AID MEASURES

EYE CONTACT

Wash with plenty of water for 15 minutes.
Consult physician if irritation develops or persists.

SKIN CONTACT

Wash with soap and water.
Consult physician if irritation develops or persists.

INHALATION

Not applicable.

INGESTION

Do not induce vomiting (aspiration hazard). Drink plenty of water and contact physician immediately.

HEALTH

1

FLAMMABILITY

0

REACTIVITY

0

LEGEND

0 = MINIMAL RISK
1 = SLIGHT RISK
2 = MODERATE RISK
3 = SERIOUS RISK
4 = SEVERE RISK

PERSONAL PROTECTION Security equipment



WHMIS



IMPORTANT: Before using RINSE-DRI always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).