

AccuFoam

HIGH FOAMING BRUSH-WASH DETERGENT

ACCUFOAM is a high-foaming, near-neutral, and cherry-fragranced liquid detergent designed specifically for carwash applications. It can be used in wand wash foamy-brush cycles and in tunnel-wash systems using either conventional rotating brushes, or the newer "soft cloth" process.

When applied, **ACCUFOAM** generates large volumes of thick, aromatic, lubricating foam that effectively lift road grime from the vehicle's surface. The foam's gentle action ensures thorough cleaning, leaving the customer with a pristine and sparkling clean car.

FEATURES & BENEFITS

- High concentration of foam-boosting surfactants
- · Suitable for both soft cloth and conventional rotating brushes
- Pleasant cherry fragrance
- Produces large volumes of lubricating foam to gently lift road grime and dirt, while preventing damage to the vehicle's paint
- · Produces neutral foaming solution on dilution, that is safe for all vehicle surfaces



DIRECTIONS FOR USE

Use procedure Use AccuFoAM for foam brush cycle in wand wash or the rotating brush/soft cloth cycle in tunnel

wash systems.

Concentration 500:1 to 1000:1 for rotating brush or soft cloth cycle in tunnel wash systems

80:1 to 120:1 for foamy brush cycle in wand wash

Use temperature Can be used in both hot and cold-water cleaning applications. For best results, use hot water

 $(50^{\circ}\text{C} - 60^{\circ}\text{C} / 120^{\circ}\text{F} - 140^{\circ}\text{F}).$

Rinsing High pressure hot water is recommended.

ACCUFOAM HIGH FOAMING BRUSH-WASH DETERGENT

PHYSICAL PROPERTIES

Appearence

Odour

Specific gravity @ 20°C

Viscosity

pН

Flash point (TCC)

Water solubility

Boiling point

Freezing point

Foaming tendency

Rinsing

Concentration monitoring techniques

Clear, yellow liquid
Cherry
1.000 – 1.020
Not available
8.0 – 9.0
None
Complete
Approx. 100°C (212°F)
Approx. 0°C (32°F)
High
Excellent
Electrical conductivity

INCOMPATIBILITY

Strong oxidizing agents, acids

WAREHOUSING PRECAUTIONS

Store away from incompatible materials
Keep from freezing

AVAILABLE SIZES

	4451	0051	
20L	115L	205L	

IMPORTANT

Before using **ACCUFOAM** always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

FIRST AID MEASURES

Ingestion

Do not induce vomiting unless directed by medical personnel. Rinse mouth with water and drink 1 or 2 glasses of water and call a POISON CENTER or doctor/physician if you feel unwell.

Skin contact

Take off contaminated clothing and rinse skin with plenty of water. If skin irritation occurs, get medical advice/attention. Wash any contaminated clothing before re-use.

Inhalation

If difficulties occur after mist, vapors, or spray has been inhaled, remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or doctor/physician if you feel unwell.

Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a POISON CENTER or doctor/physician immediately.

PERSONAL PROTECTION

















MONTREAL

10,900 rue Secant Anjou, QC H1J 1S5 Tel.: 514-355-4660 Toll free : 1 800-361-8927

EDMONTON

11411-160 Street Edmonton, Alberta T5M 3T7 Tel.: 780-454-3919 Toll free : 1 866-454-3919