

# AccuSpray NF

## SPRAY CABINET PARTS WASHER DETERGENT

**AccuSpray NF** is a low-foaming alkaline detergent for parts cleaning in spray-washer systems such as “Typhoon” and “Proceco” washers.

**AccuSpray NF** has been formulated to be extremely low foaming under use conditions, while providing efficient cleaning action.

**AccuSpray NF** is safe to use on all metals including aluminum.

## FEATURES & BENEFITS

- 100% active ingredients
- Low foaming
- Excellent solubility
- Formulated to tackle oily films and baked-on grease
- Suitable for a variety of parts washers and non-corrosive to soft metals, including aluminum



## DIRECTIONS FOR USE

### Use procedure

Add **AccuSpray NF** to water in the reservoir of the spray washer before starting up. To maintain optimum cleaning and manage foaming, add fresh **AccuSpray NF** to the cleaning solution on a weekly basis, as needed

### Concentration

For start up, add 20 to 50 grams per liter for water in the reservoir, achieving a 2% - 5% w/v concentration.

Once the spray washer is in operation, add an extra 10 grams per liter, as needed, to maintain cleaning effectiveness and suppress foaming.

### Use temperature

60°C to 80°C (140°F – 176°C)

# ACCUSPRAY NF

SPRAY CABINET PARTS WASHER DETERGENT

## PHYSICAL PROPERTIES

Appearance	White powder
Odour	Odorless
Specific gravity @ 20°C	Not applicable
Viscosity	Not applicable
pH	11.5 – 12.5 (1 % w/v solution in water)
Flash point (TCC)	None
Water solubility	Complete
Boiling point	Not applicable
Freezing point	Not applicable
Foaming tendency	Low
Concentration monitoring techniques	Electrical conductivity, titration

## INCOMPATIBILITY

Strong oxidizing agents, acids

## WAREHOUSING PRECAUTIONS

Store away from incompatible materials

## AVAILABLE SIZES

			
50Kg	100Kg	200Kg	

## IMPORTANT

Before using **ACCUSPRAY NF** always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

## FIRST AID MEASURES

### Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a POISON CENTER or doctor/physician immediately.

### Skin contact

Take off contaminated clothing and rinse skin with plenty of water. Get medical advice/attention. Wash any contaminated clothing before re-use.

### Inhalation

If difficulties occur after dust has been inhaled, remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or doctor/physician.

### Ingestion

Do not induce vomiting unless directed by medical personnel. Rinse mouth with water and drink 1 or 2 glasses of water and call a POISON CENTER or doctor/physician immediately.

## PERSONAL PROTECTION



WHMIS

