

### PRINTING INDUSTRY



**CELL-KLEEN HD2** is a viscous cleaner designed to deep clean water and solvent-based inks from anilox rolls. Because of its thixotropic properties, **CELL-KLEEN HD2** can be applied either on press or off and will allow for increased dwell time on the roll without dripping down onto other sensitive press components. **CELL-KLEEN HD2** will penetrate deeply into the cells and clean them like never before. By using **CELL-KLEEN HD2** to routinely clean anilox rolls, the frequency with which rolls need to be sent out for reconditioning will be greatly reduced and print quality will be greatly improved.

### FEATURES and BENEFITS

- Clings to vertical surfaces
- Deep cleans
- Effectively removes camouflage
- Economical: 4L cleans up to 10 rolls
- Cost and labour reductions
- Improved print quality
- Extended roll life
- Leaves no film or residue after rinsing

### DIRECTIONS FOR USE

#### Use procedure

Apply **CELL-KLEEN HD2** with a brush or coarse spray and let dwell for 15 to 30 minutes. In a very short time you will see the ink rising to the surface. Some agitation with a stainless steel or brass brush may be required depending on soil conditions.

#### Rinsing

Thoroughly rinse with water, or remove with a clean damp rag if cleaning is being done on press.

# CELL-KLEEN HD2

## DEEP-CLEANING ANILOX ROLL CLEANER

### PHYSICAL PROPERTIES

Appearance	Thick, light brown gel
Odour	Faint solvent
Specific gravity @ 20°C	1.24
Viscosity	> 2000 cps
pH	> 13.5
Water solubility	Complete
Chlorine	None
Boiling point	Approx. 100°C
Freezing point	Not available
Flash point (TCC)	None

### INCOMPATIBILITY

Acids, aluminium, zinc

### WAREHOUSING PRECAUTIONS

Store away from acid products

### FIRST AID MEASURES

#### EYE CONTACT

Wash with plenty of water for 15 minutes.  
Consult physician.

#### SKIN CONTACT

Wash with water. Consult physician  
if irritation develops or persists.

#### INHALATION

Not applicable

#### INGESTION

Do not induce vomiting. Drink plenty  
of water and contact physician.

### HEALTH

3

### FLAMMABILITY

0

### REACTIVITY

0

#### LEGEND

0 = MINIMAL RISK  
1 = SLIGHT RISK  
2 = MODERATE RISK  
3 = SERIOUS RISK  
4 = SEVERE RISK

### PERSONAL PROTECTION Security equipment



WHMIS



**IMPORTANT :** Before using **CELL-KLEEN HD2**, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the material safety data sheet (M.S.D.S.).