

## CELL-KLEEN HD2

### DEEP-CLEANING ANILOX ROLL CLEANER

**CELL-KLEEN HD2** is a viscous cleaner designed to deep clean water and solvent-based inks from anilox rolls. Because of its thixotropic properties, **CELL-KLEEN HD2** can be applied either on press or off and will allow for increased dwell time on the roll without dripping down onto other sensitive press components. **CELL-KLEEN HD2** will penetrate deeply into the cells and clean them like never before.

By using **CELL-KLEEN HD2** to routinely clean anilox rolls, the frequency with which rolls need to be sent out for reconditioning will be greatly reduced and print quality will be greatly improved.

### FEATURES & BENEFITS

- Clings to vertical surfaces
- Deep cleans
- Effectively removes camouflage
- Economical: 4L cleans up to 10 rolls
- Cost and labour reductions
- Improved print quality
- Extended roll life
- Leaves no film or residue after rinsing



### DIRECTIONS FOR USE

#### Use procedure

Apply **CELL-KLEEN HD2** with a brush or coarse spray and let dwell for 15 to 30 minutes. In a very short time you will see the ink rising to the surface. Some agitation with a stainless steel or brass brush may be required depending on soil conditions.

#### Rinsing

Thoroughly rinse with water, or remove with a clean damp rag if cleaning is being done on press.

# CELL-KLEEN HD2 DEEP-CLEANING ANILOX ROLL CLEANER

## PHYSICAL PROPERTIES

|                                     |                        |
|-------------------------------------|------------------------|
| Appearance                          | Thick, light brown gel |
| Odour                               | Faint solvent          |
| Specific gravity @ 20°C             | 1.24                   |
| Viscosity                           | >2000 cps              |
| pH                                  | >13.5                  |
| Flash point (TCC)                   | None                   |
| Water solubility                    | Complete               |
| Auto ignition temperature           | None                   |
| Boiling point                       | 100°C                  |
| Freezing point                      | Not available          |
| Foaming tendency                    | Not applicable         |
| Concentration monitoring techniques | Not applicable         |
| Rinsing                             | Excellent              |

## INCOMPATIBILITY

Strong acids

## WAREHOUSING PRECAUTIONS

Keep containers tightly closed in a dry, cool and well-ventilated place

## AVAILABLE SIZES

|   |   |  |  |
|---|---|--|--|
|  |  |  |  |
| 4 X 4L  | 205L  |  |  |

## IMPORTANT

Before using **CELL-KLEEN HD2**, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

## FIRST AID MEASURES

### Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

### Skin contact

Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse.

### Inhalation

Remove victim to fresh air and keep at rest in a position comfortable for breathing. Immediately call a POISON CENTER or doctor/physician.

### Ingestion

Do not induce vomiting. Drink 1 or 2 glasses of water. Call a physician or Poison Control Centre immediately. Never give anything by mouth to an unconscious person.

## PERSONAL PROTECTION



WHMIS

