

DuoTECH PRESOAK

CARWASH DETERGENT CONCENTRATE

DuoTECH Presoak is a liquid detergent concentrate designed for our **DuoTECH** system to produce a fragranced high-pressure soap in the presoak wand wash or touchless applications for high performance and excellent show.

DuoTECH PRESOAK effectively removes road salt and other tough to penetrate films while maintaining a favorable environmental profile. It is non-corrosive to all soft metals and is safe to use on glass, plastics, rubber, and painted surfaces and works well in both hard and soft water systems.

The surfactants in **DuoTECH PRESOAK** work synergistically with our **DuoTECH B1**, **DuoTECH B3**, or **DuoPOWER** road film cutters to create exceptional cleaning.

DuoTECH PRESOAK comes in either blue, or colorless depending on the operator's preference and use.

FEATURES & BENEFITS

- Biodegradable surfactants
- High performance and show
- Decrease overall usage
- Fewer waste containers
- Comes in either blue, or colorless
- Pleasant "Fresh & Clean" fragrance
- Suitable for foamers, wands, and touchless applications
- Wide range of dilutions are possible with the **DuoTECH** system



DIRECTIONS FOR USE

Use procedure	For touchless or wand presoak applications, combine DuoTECH PRESOAK with DuoTECH B1 , DuoTECH B3 or DuoPOWER .
Concentration	The DuoTECH system is expertly installed by your sales representative, who will customize the dilution ratios to meet your specific requirements. Typical dilution is up to 300:1 for wand and touchless presoak applications.
Use temperature	Can be used in both hot and cold-water cleaning applications. For best results, use hot water (50°C – 60°C / 120°F – 140°F).
Rinsing	High pressure hot water is recommended.

DUOTECH PRESOAK CARWASH DETERGENT CONCENTRATE

PHYSICAL PROPERTIES

Appearance	Clear, colorless or blue liquid
Odour	Mild detergent
Specific gravity @ 20°C	1.000 – 1.020
Viscosity	Not available
pH	7.0 – 8.0
Flash point (TCC)	Not applicable
Water solubility	Complete
Boiling point	Approx. 100°C (212°F)
Freezing point	Not available
Foaming tendency	High
Rinsing	Excellent
Concentration monitoring techniques	Not available

INCOMPATIBILITY

Strong oxidizing agents

WAREHOUSING PRECAUTIONS

Keep containers tightly closed in a dry, cool, and well-ventilated place

AVAILABLE SIZES

			
20L	115L	205L	

IMPORTANT

Before using **DUOTECH PRESOAK** always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

FIRST AID MEASURES

Ingestion

Rinse mouth. Do NOT induce vomiting. Call a POISON CENTER or doctor/physician if you feel unwell.

Skin contact

Wash with plenty of water. If skin irritation occurs, get medical advice/attention. Take off contaminated clothing and wash before reuse.

Inhalation

If difficulties occur after mist, vapors, or spray has been inhaled, remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or doctor/physician if you feel unwell.

Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a POISON CENTER or doctor/physician immediately.

PERSONAL PROTECTION



WHMIS

