

## KLEEN-EZEY

### MANUAL ACID CLEANER

**KLEEN-EZEY** is a manual inhibited acid cleaner and milkstone remover. It is especially effective for the manual cleaning of food, beverage and dairy plant processing equipment.

It exhibits exceptional wetting and cleaning action and may be used in strong concentrations without fear of harmful results to most surfaces.

This product possesses unique penetrating and cleansing power that enables it to get under protein and soil deposits, thereby leaving surfaces completely cleaned.

### FEATURES AND BENEFITS

- Biodegradable
- Lifts protein and soil deposits easily
- Concentrated product contains a high percentage of food grade phosphoric acid and cationic detergent
- Corrosion inhibitor
- Does not release gases or unpleasant odours



### DIRECTION FOR USE

<b>Equipment to be treated</b>	Food and beverage equipment and premises.
<b>Soils to be removed</b>	Mineral deposits i.e. scale, milk stone, water stains, beer stone.
<b>Use procedure</b>	If possible degrease surfaces, apply <b>KLEEN-EZEY</b> automatically or manually.
<b>Concentration</b>	
<i>General use:</i>	0.2% to 2% (2 ml to 20 ml / litre).
<i>Milkstone and rust:</i>	5% to 15 % (50 ml to 150 ml / litre).
<b>Temperature</b>	40°C to 70°C. (59 to 158°F).
<b>Dwell time/Operation time</b>	At least 15 minutes.
<b>Mechanical action</b>	Mechanical action always help.
<b>Rinsing</b>	Rinse surfaces in contact with food with potable water.

# KLEEN-EZEY MANUAL ACID CLEANER

## PHYSICAL PROPERTIES

Appearance	Clear, amber liquid
Odour	Faint detergent
Specific gravity @ 20°C	1.2
Viscosity	< 10 cps
pH	< 1
Flash point (TCC)	None
Water solubility	Complete
Auto ignition temperature	None
Chlorine	None
Boiling point	100°C
Freezing point	Not available
Foaming tendency	Moderate
Concentration monitoring techniques	Electrical conductivity, refractive index, titration
Rinsing	Excellent

## INCOMPATIBILITY

Bases, organic materials, light metals, bleach

## WAREHOUSING PRECAUTIONS

Keep containers tightly closed in a dry, cool and well-ventilated place

## AVAILABLE SIZES

			
4 X 4L	20L	205L	



## IMPORTANT

Before using **KLEEN-EZEY**, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

## FIRST AID MEASURES

### Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

### Skin contact

Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse.

### Inhalation

Remove person to fresh air and keep at rest in a position comfortable for breathing. Immediately call a POISON CENTER or doctor/physician.

### Ingestion

Do not induce vomiting. Drink 1 or 2 glasses of water. Call a physician or Poison Control Centre immediately. Never give anything by mouth to an unconscious person.

## PERSONAL PROTECTION



WHMIS

