

PENBLITZ 228M

HEAVY-DUTY ALKALINE CLEANER

PENBLITZ 228M is a caustic free liquid alkaline cleaner.

PENBLITZ 228M is high foaming which allows its use in heavy-duty automatic foaming systems.

PENBLITZ 228M ffective on a wide variety of deposits and soils such as lubricants, rubber marks on shipping floors, animal fat, ink, adhesives, shoe marks and wax.

FEATURES & BENEFITS

- Caustic free
- Phosphate free
- High foaming
- Solvent free
- Low viscosity
- Odourless
- Safe for users and compatible with most metallic and non metallic materials
- Non flammable
- Non volatile



DIRECTIONS FOR USE

Use procedure Apply using a mop, trigger or automatic sprayer or automatic foaming system.

Concentration Between 12% and 10%.

Use temperature Preferably above 50°C.

Dwell time/Operation time Allow to dwell 3 to 5 minutes before final rinsing.

Mechanical action Scrubbing, high pressure application and rinsing recommended to remove stubborn deposits.

Rinsing High pressure hot water.

PHYSICAL PROPERTIES

Appearence

Odour

Specific gravity @ 20°C

Viscosity

рΗ

Flash point (TCC)

Water solubility

Boiling point

Freezing point

Foaming tendency

Rinsing

High

Excellent

Concentration monitoring techniques

Clear, colorless liquid
Faint detergent
1.07
<10 cps
13
None
Complete
100°C (212°F)
Not available

Electrical conductivity, titration

INCOMPATIBILITY

Strong acids

WAREHOUSING PRECAUTIONS

Keep containers tightly closed away from direct sunlight in a dry, cool and well-ventilated place

AVAILABLE SIZES







4X4L

20L

205L

1000L



IMPORTANT

Before using PENBLITZ 228M, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

FIRST AID MEASURES

Ingestion

Do not induce vomiting. Drink 1 or 2 glasses of water. Call a physician or Poison Control Centre immediately. Never give anything by mouth to an unconscious person.

Skin contact

Remove/Take off immediately all contaminated clothing. Rinse skin with water/ shower. Wash contaminated clothing before reuse.

Inhalation

Remove victim to fresh air and keep at rest in a position comfortable for breathing Immediately call a POISON CENTER or doctor/physician.

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/ physician.

PERSONAL PROTECTION















MONTREAL

10,900 rue Secant Aniou, OC H1I 1S5 Tel.: 514-355-4660 Toll free: 1 800-361-8927

EDMONTON

11411-160 Street Edmonton, Alberta T5M 3T7 Tel.: 780-454-3919 Toll free: 1 866-454-3919