

PENSCRUB AG-150

Iron sulfide scale control & low-ph H_2 s remediation

PENSCRUB AG-150 is a low-pH scale mitigation aid designed to control excessive evolution of hydrogen sulfide gas in pyrophoric and non-pyrophoric iron sulfide remediation procedures employed in post-operational cleaning applications.

The inhibited formulation also reduces pitting, corrosion or cracking in a variety of vessel, unit or line application procedures.

FEATURES & BENEFITS

- High acid strength
- · Contains no added formaldehyde
- · Contains corrosion inhibitor
- Controls residual iron scale precipitation
- Provides rapid scale dissolution
- Dramatically reduces turn-around time
- Low-fuming
- Easily diluted to desired concentration
- Compatible with a variety of pH indicators to visually monitor changes in pH



DIRECTIONS FOR USE

Use procedure

Use **PENSCRUB AG-150** as part of a circulation, immersion or cascade chemical cleaning application. Rinse procedure recommended.

Consult with your local West Penetone sales representative for the procedures best suited for your application.

Concentration

Preliminary recommendations include a minimum concentration of 10% v/v with water for all applications.

Use temperature

Ambient temperature to $40^{\circ}\text{C-}50^{\circ}\text{C}$ ($104^{\circ}\text{F-}122^{\circ}\text{F}$) is recommended. Reaction rate for abating H_{2}S slows at lower temperatures.

Dwell time / Operation time

Dependent on job, site and method of application. Retain monitoring is recommended.

PHYSICAL PROPERTIES

Appearence

Odour

Specific gravity @ 20 °C

Viscosity

Flash point (TCC)

Water solubility

Boiling point

Freezing point

Foaming tendency

Rinsing

Concentration monitoring techniques

Clear, colorless to yellow liquid		
Acidic		
1.125-1.130		
Not available		
<1.0		
None		
Complete		
Not available		
Approx40°C (-40°F)		
Moderate		
Excellent		

INCOMPATIBILITY

Strong or chlorinated alkali, amphoteric or light metals

WAREHOUSING PRECAUTIONS

Keep containers tightly closed away from direct sunlight in a dry, cool and well-ventilated place

AVAILABLE SIZES

20L	205L	1000L

IMPORTANT

Before using PENSCRUB AG-150, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

pH, titration

FIRST AID MEASURES

Ingestion

Do not induce vomiting. Drink 1 or 2 glasses of water. Call a physician or Poison Control Centre immediately. Never give anything by mouth to an unconscious person.

Skin contact

Take off immediately all contaminated clothing. Rinse skin with soap and water/ shower. Wash contaminated clothing before reuse.

Inhalation

Remove victim to fresh air and keep at rest in a position comfortable for breathing. Immediately call a POISON CENTER or doctor/physician.

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/ physician.

PERSONAL PROTECTION





















MONTREAL

10,900 rue Secant Aniou, OC H1I 1S5 Tel.: 514-355-4660 Toll free: 1 800-361-8927

EDMONTON

11411-160 Street Edmonton, Alberta T5M 3T7 Tel.: 780-454-3919 Toll free: 1 866-454-3919