

LAUNDRY



CYCLONE is an exceedingly versatile, mild alkaline cleaner and degreaser designed to remove a multitude of grease or oils, dirt, debris, and residues safely for fabrics in laundry settings. Designed for general cleaning and stain removal or as a boost for other detergent and cleaning additives in industrial laundry systems.

FEATURES AND BENEFITS

- High foaming
- Phosphate free
- BOD data available
- Cost efficient
- Versatile application methods

DIRECTIONS FOR USE

| | |
|--------------------------|--|
| System use | Use in manual or automatic laundry systems located in industrial, commercial, or hospitality settings. |
| Concentration | Add 415-830 mL or approximately 2-3.5 cups per 50 lb wash load, depending on severity of soils. |
| Use temperature | Effective in both hot and cold water. |
| Cycle of addition | Add directly to wash cycle. |

CYCLONE

LIQUID DETERGENT AND ALKALI BUILDER

PHYSICAL PROPERTIES

| | |
|-------------------------------------|---------------|
| Appearance | Blue liquid |
| Odour | Detergent |
| Specific Gravity @ 20°C | 1.065-1.080 |
| Viscosity | Thin |
| pH | 12.0-13.5 |
| Flash Point (TCC) | None |
| Boiling Point | Approx. 100°C |
| Freezing Point | Approx. 0°C |
| Foaming Tendency | High |
| Concentration Monitoring Techniques | Titration |
| Rinsability | Excellent |
| Water solubility | Complete |




INCOMPATIBILITY

Strong acids and oxidizing materials
Avoid contact with aluminum or galvanized surfaces or prolonged contact with copper or brass materials

WAREHOUSING PRECAUTIONS

Keep from freezing

AVAILABLE SIZES

| | | | |
|--|--|--|--|
|  |  |  |  |
| 20L | 60L | 120L | 205L |

FIRST AID MEASURES

EYE CONTACT

Wash with plenty of water for 15 minutes. Consult physician if irritation develops or persists.

SKIN CONTACT

Wash with plenty of water for 15 minutes. Apply skin cream if required. Consult physician if irritation develops or persists.

INHALATION

Give fresh air. Consult physician.

INGESTION

Do not induce vomiting. Drink plenty of water and contact physician.

HEALTH

2

FLAMMABILITY

0

REACTIVITY

0

LEGEND

0 = MINIMAL RISK
1 = SLIGHT RISK
2 = MODERATE RISK
3 = SERIOUS RISK
4 = SEVERE RISK

PERSONAL PROTECTION Security equipment



WHMIS



IMPORTANT: Before using CYCLONE, always be sure to read and follow precautions and directions for use appearing on the product container label and on the material safety data sheet (m.s.d.s.).