

WASH BAY - LIQUID CLEANERS



**GLISTEN** is a liquid alkaline cleaner designed for use in water recycling wash systems. Its high foaming capacity and low residence time will not adversely effect separators or holding tanks.

FEATURES AND BENEFITS

- High foaming
- Low residence time
- Low viscosity
- Compatible with most metallic and non metallic materials
- Non volatile
- Non flammable
- Will not reduce the capacity of pumps, tanks, or separators over time

DIRECTIONS FOR USE

<b>Use procedure</b>	Use <b>GLISTEN</b> as directed. May be used manually or with adequate foaming or high-pressure systems. Scour or brush stubborn deposits.
<b>Concentration</b>	Between 1%-10%, depending on type of re-circulating system and amount of soils present.
<b>Use temperature</b>	Most effective in hot, soft water.
<b>Dwell time / Operation time</b>	Allow to dwell 3 to 5 minutes before final rinsing.
<b>Mechanical action</b>	Scrubbing, high pressure application and rinsing recommended for removing stubborn deposits.
<b>Rinsing</b>	High pressure hot water.

# GLISTEN

## CLEANER FOR VEHICLE EXTERIOR

### PHYSICAL PROPERTIES

Appearance	Pink liquid
Odour	Detergent/solvent
Specific Gravity @ 20°C	1.068
Viscosity	Thin
pH	11.5
Flash Point (TCC)	None
Boiling Point	Approx. 100°C
Freezing Point	Approx. -10°C
Foaming Tendency	High
Concentration Monitoring Techniques	Titration
Rinsability	Excellent
Water Solubility	Complete

### INCOMPATIBILITY

Acids and oxidizing materials

### WAREHOUSING PRECAUTIONS

Keep from freezing

### AVAILABLE SIZES

			
20L	205L		

### FIRST AID MEASURES

#### EYE CONTACT

Wash with plenty of water for 15 minutes. Consult physician if irritation develops or persists.

#### SKIN CONTACT

Wash with plenty of water for 15 minutes. Consult physician if irritation develops or persists.

#### INHALATION

Not applicable.

#### INGESTION

Do not induce vomiting. Drink plenty of water and contact physician.

### HEALTH

1

### FLAMMABILITY

0

### REACTIVITY

0

#### LEGEND

0 = MINIMAL RISK  
1 = SLIGHT RISK  
2 = MODERATE RISK  
3 = SERIOUS RISK  
4 = SEVERE RISK

### PERSONAL PROTECTION Security equipment



WHMIS



**IMPORTANT:** Before using GLISTEN, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).