

### LAUNDRY



**PENTECH-D** is a high pH, liquid detergent designed to provide rapid dispersion and removal of heavy oils or greases, soils, and other organic materials found in a variety of laundry applications including industrial washing or work-wear fabric cleaning. It is effective and safe on a variety of fabrics when applied at the recommended dilution ratios.

### FEATURES AND BENEFITS

- No VOC's
- High alkali for rapid soil removal and suspension
- Contains no phosphates or solvents
- Effective in hard or soft water

### DIRECTIONS FOR USE

<b>Use procedure</b>	Add <b>PENTECH-D</b> via injection pump system directly to wash cycle. For optimum results, use in combination with West Penetone laundry care products.
<b>Concentration</b>	Use 400-800 mL or approximately 1.5-3.5 cups per 50 lb wash load or at a maximum pump injection rate of 2.5 to 2.6 oz/gal for all automatic laundry systems.
<b>Temperature</b>	Most effective in hot water.

# PENTECH-D

## LIQUID ALKALINE DETERGENT & BUILDER

### PHYSICAL PROPERTIES

Appearance	Red liquid
Odour	Detergent
Specific gravity @ 20°C	1.125-1.135
Viscosity	Thin
pH (1% v/v solution)	12.5
Flash point (TCC)	None
Boiling point	Approx. 100°C
Freezing point	Approx. -5°C
Foaming tendency	Low
Concentration monitoring techniques	Not determined
Rinsing	Excellent
Water solubility	Complete

### INCOMPATIBILITY

Strong acids and oxidizing materials

Avoid contact with aluminum or galvanized surfaces or prolonged contact with copper or brass materials

### WAREHOUSING PRECAUTIONS

Keep from freezing  
Keep container closed when not in use

### AVAILABLE SIZES

			
20L	205L		

### FIRST AID MEASURES

#### EYE CONTACT

Wash with plenty of water for 15 minutes. Consult physician if irritation develops or persists.

#### SKIN CONTACT

Wash with plenty of water for 15 minutes. Apply skin cream if required. Consult physician if irritation develops or persists.

#### INHALATION

Give fresh air. Consult physician.

#### INGESTION

Do not induce vomiting. Drink plenty of water and contact physician immediately.

### HEALTH

3

### FLAMMABILITY

0

### REACTIVITY

0

### LEGEND

0 = MINIMAL RISK  
1 = SLIGHT RISK  
2 = MODERATE RISK  
3 = SERIOUS RISK  
4 = SEVERE RISK

### PERSONAL PROTECTION Security equipment



WHMIS



**IMPORTANT:** Before using PENTECH-D always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).