

BIO-LOGIC



PROZYME GT is a ready to use proprietary bio-formulation designed specifically to eliminate organic waste and unpleasant odours in grease traps and drain lines.

PROZYME GT contains non-toxic, non-pathogenic bacteria that digest and liquefy dead organic waste such as fat, grease, proteins and other food-based particles.

FEATURES AND BENEFITS

- Ready to use
- Highly concentrated bacterial formulation
- Ecologo certified formulation available with the product Enviro Trap
- Significantly reduces the need for grease trap pumpouts
- Eliminates disagreeable odours
- Converts organic matter into carbon dioxide and water
- No effect on PVC / plastic piping

DIRECTIONS FOR USE

Use procedure

GREASE TRAP

PROZYME GT can be poured manually into the trap or injected with an automatic dispensing system. Dosage may vary depending on the size of the trap and soil load. Contact your local West Penetone sales representative for the necessary equipment and dosage rates for your grease trap.

DRAINS

Pour product at a rate of 4 – 8 oz or approximately 120 – 240 mL or approximately 1/2 – 1 cup per week directly into the drain.

NOTE: performance may be affected in pH conditions under 5 or over 9.8.



PROZYME GT

BIOLOGICAL GREASE TRAP ADDITIVE

PHYSICAL PROPERTIES

Appearance	White liquid
Odour	Detergent
Specific Gravity @ 20°C	1.0
Viscosity	Thin
pH	7-8
Flash Point (TCC)	None
Boiling Point	Approx. 100°C
Freezing Point	Approx. 0°C
Foaming Tendency	Nil
Water Solubility	Complete


INCOMPATIBILITY

Oxidizers, sanitizers

WAREHOUSING PRECAUTIONS

Keep from freezing

AVAILABLE SIZES

			
20L			

FIRST AID MEASURES

EYE CONTACT

Wash with plenty of water for 15 minutes. Contact physician if irritation persists or develops.

SKIN CONTACT

Wash with soap and water.

INHALATION

Not applicable

INGESTION

Do not induce vomiting. Drink 1 or 2 glasses of water and contact physician immediately.

HEALTH

0

FLAMMABILITY

0

REACTIVITY

0

LEGEND

0 = MINIMAL RISK
1 = SLIGHT RISK
2 = MODERATE RISK
3 = SERIOUS RISK
4 = SEVERE RISK

PERSONAL PROTECTION Security equipment



WHMIS



IMPORTANT: Before using PROZYME GT, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).