

AccuTERGE C

PRESSURE WASHER DETERGENT

AccuTERGE C is a concentrated liquid vehicle wash detergent designed to eliminate the inconvenience associated with the handling of powdered detergents. **AccuTERGE C** is a specially balanced formulation that works well on heavy-duty truck wash applications but is safe to use on the finest automobile finishes.

AccuTERGE C is a high foaming product designed to give maximum visual appeal to the carwash customer. This product works well in both hard and soft water areas. Carwash operators have installed water-softening equipment will achieve good performance at lower product concentrations.

FEATURES & BENEFITS

- Excellent on road film, bugs, windshield eyebrows, and road salts
- Safe for all types of pressure washers
- Suitable for any car wash that uses foamers, wands, and touchless applications
- Easy rinsing and high foaming product
- Effective at high dilution rates



DIRECTIONS FOR USE

Use procedure

Use **AccuTERGE C** as a presoak, detergent, and foaming soap in “touchless” and “wand wash” carwash applications in either soft or hard water environments. Typically, **AccuTERGE C** can be used in both hot and cold-water cleaning applications. For the best results hot water and a gun pressure of 1000 to 1200 PSI are recommended. Lower temperatures and pressures will require a higher product concentration for efficient road film removal. **AccuTERGE C** can be directly metered to wash solution to give a consistent soap concentration. Eliminating the inconsistencies and inconvenience associated with mixing and dissolving powders.

Concentration

60:1 to 100:1 touchless or foamer applications
 200:1 to 400:1 for high-pressure wand wash
 Dilution rates will depend on water hardness and water temperature. Lower water temperatures or hard water may require a higher product concentration for efficient road film removal.

Use temperature

Can be used in both hot and cold-water cleaning applications. For the best results, hot water (50°C – 60°C / 120°F – 140°F) and wand pressure of 1000 to 1200 PSI are recommended.

Rinsing

High pressure hot water is recommended.

ACCUTERGE C PRESSURE WASHER DETERGENT

PHYSICAL PROPERTIES

Appearance	Clear, blue liquid
Odour	Mild detergent
Specific gravity @ 20°C	1.110 - 1.130
Viscosity	Not available
pH	12.0 – 13.0
Flash point (TCC)	None
Water solubility	Complete
Boiling point	Approx. 100°C (212°F)
Freezing point	Approx. 0°C (32°F)
Foaming tendency	High
Rinsing	Excellent
Concentration monitoring techniques	Electrical conductivity, titration

INCOMPATIBILITY

Strong oxidizing agents, acids

WAREHOUSING PRECAUTIONS

Store away from incompatible materials.
Keep from freezing

AVAILABLE SIZES

			
20L	205L	1040L	

IMPORTANT

Before using **ACCUTERGE C** always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

FIRST AID MEASURES

Ingestion

Do not induce vomiting unless directed by medical personnel. Rinse mouth with water and drink 1 or 2 glasses of water and call a POISON CENTER or doctor/physician immediately.

Skin contact

Take off contaminated clothing and rinse skin with plenty of water. Get medical advice/attention. Wash any contaminated clothing before re-use.

Inhalation

If difficulties occur after mist/vapors/spray has been inhaled, remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or doctor/physician.

Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a doctor/physician immediately.

PERSONAL PROTECTION



WHMIS

