

## BIO-EZE 3

### BIODEGRADABLE FOAMING ALKALINE DEGREASER

**BIO-EZE 3** is a new generation foaming alkaline cleaner designed to be safely used on all kinds of surfaces such as vinyl, leather, fabric and painted surfaces.

**BIO-EZE 3** easily and effectively removes dirt, stains, oil and grease. It can also be used as a glass cleaner at dilution rate of 2% to 5%, according to degree of difficulty.

### FEATURES AND BENEFITS

- Highly effective
- Ecologo certified Degreaser and industrial cleaners: UL-2700
- High foaming
- Readily biodegradable
- Water soluble
- Phosphate free
- Non corrosive



### DIRECTIONS FOR USE

#### Surfaces to be cleaned

Premises and equipment in agricultural and horticultural industry and equipment and premises in food processing industry. Vehicles, engines, tires and parts.

#### Soils to be removed

Dirt, soil, food deposits, fats, grease, blood.

#### Use procedures

Once all food debris is removed, rinse surfaces with hot water and then apply a foam solution of **BIO-EZE 3** with appropriate equipment. Allow to dwell then rinse with hot water to remove all product residue. (Rinse surfaces in contact with food with potable water).

#### Concentration

Between 2% and 5% (20 ml and 50 ml/litre of water).

#### Temperature

Between 5 and 60°C.

#### Dwell time/Operation time

Between 2 to 25 minutes.

#### Mechanical action

For highly resistant soils, scrub with pad or brush.

**NOTE:** **BIO-EZE 3** may tarnish aluminum surfaces. Pretest before using.

# BIO-EZE 3 BIODEGRADABLE FOAMING ALKALINE DEGREASER

## PHYSICAL PROPERTIES

Appearance	Clear, pale yellow liquid
Odour	Detergent
Specific gravity @ 20 °C	1.02
Viscosity	< 10 cps @ 22°C
pH	10.5
Flash point (TCC)	None
Water solubility	Complete
Auto ignition temperature	None
Chlorine	None
Boiling point	100°C
Freezing point	Not available
Foaming tendency	High
Concentration monitoring techniques	Electrical conductivity, refractive index
Rinsing	Excellent

## INCOMPATIBILITY

None

## WAREHOUSING PRECAUTIONS

Keep containers tightly closed in a dry, cool and well-ventilated place

## AVAILABLE SIZES

			
4 X 4L	20L	205L	



## IMPORTANT

Before using **BIO-EZE 3**, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

## FIRST AID MEASURES

### Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

### Skin contact

Rinse skin with water. Wash contaminated clothing before reuse.

### Inhalation

Not applicable.

### Ingestion

Do not induce vomiting. Drink 1 or 2 glasses of water. Call a physician or Poison Control Centre immediately. Never give anything by mouth to an unconscious person.

## PERSONAL PROTECTION



WHMIS



### MONTREAL

10,900 rue Secant  
Anjou, QC H1J 1S5  
Tel.: 514-355-4660  
Toll free : 1 800-361-8927

### EDMONTON

11411-160 Street  
Edmonton, Alberta T5M 3T7  
Tel.: 780-454-3919  
Toll free : 1 866-454-3919