

KLEEN-EZEY

INHIBITED ACID CLEANER

KLEEN-EZEY is an inhibited, medium-foaming acid cleaner designed for a variety of applications including scale removal, cleaning food or beverage processing equipment, and as an acidic pre-soak in vehicle wash cleaning applications.

The inhibited formulation allows for use at high concentrations without risk to most surfaces to penetrate and clean under a variety of soil deposits.

FEATURES & BENEFITS

- Moderate foaming liquid
- Low viscosity
- Water dilutable
- Concentrated product containing corrosion inhibitor and cationic detergent
- Lifts soil deposits easily
- Does not release gases or unpleasant odors
- May be used with foaming equipment to increase contact time



DIRECTIONS FOR USE

Use procedure	Apply to surfaces free of excess debris and oils or grease. May be used manually or with an adequate foaming or low-pressure system. Scour or brush stubborn deposits. Re-apply if necessary.
Concentration	<p>Foamer applications, 19:1 to 7:1 or approximately 5 - 15% v/v with water.</p> <p>For acidic pre-soak vehicle wash applications: Low-pressure spray, 480:1 to 48:1 or approximately 0.2 —2.0% v/v with water.</p> <p>For heavy build-up, more than one application may be required.</p>
Use temperature	Warm to hot water.
Dwell time/Operation time	Minimum of 15 minutes is recommended.
Rinsing	Ensure thorough rinsing of surfaces in contact with food using potable water.

KLEEN-EZEY

INHIBITED ACID CLEANER

PHYSICAL PROPERTIES

Appearance

Clear, amber liquid

Odour

Faint detergent

Specific gravity @ 20°C

1.2

Viscosity

<10 cps

pH

<1

Flash point (TCC)

None

Water solubility

Complete

Boiling point

100°C (212°F)

Freezing point

Not available

Foaming tendency

Moderate

Rinsing

Excellent

Concentration monitoring techniques

Titration, electrical conductivity, refractive index

INCOMPATIBILITY

Bases, organic materials, light metals, bleach

WAREHOUSING PRECAUTIONS

Keep containers tightly closed away from direct sunlight in a dry, cool and well-ventilated place, away from incompatible materials.

AVAILABLE SIZES



4L



20L



205L



IMPORTANT

Before using **KLEEN-EZEY**, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S.).

FIRST AID MEASURES

Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

Skin contact

Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse.

Inhalation

Remove person to fresh air and keep at rest in a position comfortable for breathing. Immediately call a POISON CENTER or doctor/physician.

Ingestion

Do not induce vomiting. Drink 1 or 2 glasses of water. Call a physician or Poison Control Centre immediately. Never give anything by mouth to an unconscious person.

PERSONAL PROTECTION



WHMIS



MONTREAL

10,900 rue Secant
Anjou, QC H1J 1S5
Tel.: 514-355-4660
Toll free : 1 800-361-8927

EDMONTON

11411-160 Street
Edmonton, Alberta T5M 3T7
Tel.: 780-454-3919
Toll free : 1 866-454-3919