

TITAN PLUS

Automatic dishwasher detergent

TITAN PLUS is a low-foaming, high alkali liquid detergent designed for use in automatic warewashing machines under all water conditions, including extreme hard water areas. It rapidly removes food soils and eliminates water spotting to provide a rapid, streak-free shine.

For use in all types of automatic warewashing equipment and dispensers located in hospitality, health care, food processing, and restaurant settings.

FEATURES & BENEFITS

- Low foaming
- High alkali content for rapid solubilisation and removal of food soils
- · Contains added detergent for reducing films and providing better rinsing
- Fast-acting
- Inhibits scale formation on machine surfaces and clean
- Effective under all temperature conditions
- Effective in extreme hard water areas



DIRECTIONS FOR USE

Use procedure

Add TITAN PLUS via automatic injection pump system directly to wash cycle.

For optimum results, use in combination with West Penetone companion rinse aid and sanitizer

products.

Dispenser dilution rates

1.5-2.5 ml/L for normal water conditions.

3.0-4.0 ml/L for extreme hard water conditions.

Use temperature

Effective in both hot and cold water.

TITAN PLUS AUTOMATIC DISHWASHER DETERGENT

PHYSICAL PROPERTIES

Appearence

Odour

Specific gravity @ 20°C

рΗ

Flash point (TCC)

Water solubility

Boiling point

Freezing point

Foaming tendency

Concentration monitoring techniques

Clear, tan liquid

Perfumed

1.02

Not available

12.5-13.5

None

Complete

Approx. 100°C (212°F)

Approx. -15°C (5°F)

Non-foaming

Excellent

Titration

INCOMPATIBILITY

Strong oxidizing materials, acids, amphoteric or light metals

WAREHOUSING PRECAUTIONS

Keep containers tightly closed away from direct sunlight in a dry, cool and well-ventilated place

AVAILABLE SIZES



4 X 4L



2 X 10L







20L

205L

IMPORTANT

Before using TITAN PLUS always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

FIRST AID MEASURES

Ingestion

Rinse mouth. Do NOT induce vomiting. Immediately call a POISON CENTER or doctor/physician.

Skin contact

Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse.

Remove person to fresh air and keep comfortable for breathing. Immediately call a POISON CENTER or doctor/physician.

Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/ physician.

PERSONAL PROTECTION

















MONTREAL

10,900 rue Secant Anjou, QC H1J 1S5 Tel.: 514-355-4660 Toll free: 1 800-361-8927

EDMONTON

11411-160 Street Edmonton, Alberta T5M 3T7 Tel.: 780-454-3919 Toll free: 1 866-454-3919