

TRUFOAM

HIGH FOAMING BRUSH-WASH DETERGENT

TRUFOAM is a high-foaming, near-neutral, and strongly colored liquid detergent designed specifically for carwash applications. It can be used in wand wash foamy-brush cycles and in tunnel-wash systems featuring either conventional rotating brushes, or the newer “soft cloth” process. **TRUFOAM** is available as red, blue and yellow options.

When applied, **TRUFOAM** generates large volumes of thick, brightly coloured, lubricating foam that effectively lift road grime from the vehicle’s surface. The foam’s gentle action ensures thorough cleaning, leaving the customer with a pristine and sparkling clean car.

FEATURES & BENEFITS

- High concentration of foam-boosting surfactants
- Suitable for both soft cloth and conventional rotating brushes
- Brightly colored foam and mild cherry fragrance
- Available in red, blue and yellow options
- Produces large volumes of lubricating foam to gently lift road grime and dirt, while preventing damage to the vehicle’s paint
- Neutral foaming solution safe for all vehicle surfaces



DIRECTIONS FOR USE

Use procedure	Use TRUFOAM for foam brush cycle in wand wash operations or to lubricate the rotating brush/soft cloth in tunnel wash systems.
Concentration	500:1 for rotating brush/soft-cloth cycle of tunnel wash systems. 60 to 100:1 for foamy brush cycle in wand wash.
Use temperature	Can be used in both hot and cold-water cleaning applications. For best results, use hot water (50°C – 60°C / 120°F – 140°F).
Rinsing	High pressure hot water is recommended.

TRUFOAM HIGH FOAMING BRUSH-WASH DETERGENT

PHYSICAL PROPERTIES

Appearance	Clear, red, blue or yellow liquid
Odour	Cherry
Specific gravity @ 20°C	1.015 – 1.035
Viscosity	Not available
pH	7.0 – 9.0
Flash point (TCC)	None
Water solubility	Complete
Boiling point	Approx. 100°C (212°F)
Freezing point	Approx. 0°C (32°F)
Foaming tendency	Very high
Rinsing	Excellent
Concentration monitoring techniques	Electrical conductivity

INCOMPATIBILITY

Strong oxidizing agents, acids

WAREHOUSING PRECAUTIONS

Store away from incompatible materials
Keep from freezing

AVAILABLE SIZES

			
20L	115L	205L	

IMPORTANT

Before using **TRUFOAM** always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

FIRST AID MEASURES

Ingestion

Do not induce vomiting unless directed by medical personnel. Rinse mouth with water and drink 1 or 2 glasses of water and call a POISON CENTER or doctor/physician if you feel unwell.

Skin contact

Take off contaminated clothing and rinse skin with plenty of water. If skin irritation occurs, get medical advice/attention. Wash any contaminated clothing before re-use.

Inhalation

If difficulties occur after mist, vapors, or spray has been inhaled, remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or doctor/physician if you feel unwell.

Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a POISON CENTER or doctor/physician immediately.

PERSONAL PROTECTION



WHMIS



MONTREAL

10,900 rue Secant
Anjou, QC H1J 1S5
Tel.: 514-355-4660
Toll free : 1 800-361-8927

EDMONTON

11411-160 Street
Edmonton, Alberta T5M 3T7
Tel.: 780-454-3919
Toll free : 1 866-454-3919